

1. After the download is complete, open the new program named “LezyneGPSupdater.exe”
- 2a. The firmware version currently on your Lezyne GPS Device will be displayed at the top of the updater. The firmware version you are about to load onto the device will be noted in the button at the bottom of the window. Click the button at the bottom of the window to update your device.

IMPORTANT: You must ensure your Lezyne GPS Device does not come unplugged once the update has begun.



2b. If any problems persist with your device, it is possible to erase all of the files and reset the device to the default factory settings by going to the toolbar menu.

